



1. Open web browser.
2. Type [https://\[IP Address of your Bridge\]](https://[IP Address of your Bridge]) in address bar.
Example: <https://11.22.33.44>

Please note, if you have not loaded an SSL certificate and assigned the bridge a DNS name, you will receive an SSL Certificate error. This is due to the bridge using its own internal, self-signed certificate. This is safe, but causes the below error in most web browsers.




Click **Advanced**, then click **Continue to [IP Address]**




The above example is using the most recent version of Microsoft Edge. Other browsers may have different ,but similar, steps.

This will take you to the Lockt login screen.




3. Enter your username (case sensitive) and password.

- You are now logged into Lockt Software.



- To log out, choose the Menu button.



- Choose Sign Out.